P802 3D Printer Wiring Guide

Ver3.0.2

- Attention.
- Zonestar Melzi-V3 new feature.
- P802-N/Q Wiring Diagram.
- P802-N/Q Wiring Diagram(With Auto Leveling)
- wiring cable description.
- Step Motors Wiring.
- Limit Switch (Endstop)Wiring.
- Power Supply Wiring.



!Attention!



The picture in this file may not match the actual machine, just for reference only.



Take care when installation, to avoid electrical shock hazards!




Once the connection is completed, please confirm again that the wrong wiring may damage the electronic device!




Some parts of the operating current is larger, please make sure the contact is good .











Melzi V3 New Feature




- 1. PCB color change to blue and optimize layout
- 2. Use high quality tantalum capacitor
- 3. Endstop's voltage switch to 5V
- 4. Serial double Z motor connector
- 5. New Zonestar® trademark



P802-N/Q Wiring Diagram








P802-N/Q Wiring Diagram(With Auto Leveling)







Wire and cable



Name	FIG	Unit	Qty.	Description
Motor wire	3	pcs	5	
DC Power	1	pcs	2	
Z Endstop	2	PCS	1	
Y Endstop	2	PCS	1	
AC power cord	5	PCS	1	
LCD cable	4	PCS	1	
USB Cable	6	PCS	1	




Step Motors Wiring

How to change the direction of step motor

exchange the sequence of the motor line, the motor deriction will be reversed

4Pin connector plug to control board and 6Pin connector plug to motor









1.use a tweezers pull out the wire from the connector



2.pull out the wire



3.re-insert





Limit Switch (Endstop)Wiring

X limit switch

Y limit switch

Z Endstop









Power Supply Wiring



Note:

V- is labeled as

COM on some

power supply.



The voltage of power supply is different depending on the country. Before wiring, please make sure this setting is right.



AC power L, N, G must be correctly distinguished, or may endanger personal safety!



Board+

Board-

AC line color:

⊋ Blue: N

Brown: I

Attention:

copper exposure is dangerous in AC line

