



- Step 1:**
Prime and glue the Axle Peg Mount and Spring Mount to the Carriage Sleeve Body.
- Step 2:**
After the glue has fully set, drill the 1/4" hole in the Axle Peg Mount/Carriage Sleeve Body.
- Step 3:**
Test fit the Axle Peg. It must slide freely in the Axle Peg Mount hole. Enlarge the hole if needed.

Carriage Sleeve Assembly

- Materials List:**
- 1 - Carriage Sleeve Body
 - 1 - Carriage Sleeve Spring Mount
 - 1 - Carriage Sleeve Axle Peg Mount
 - 1 - Axle Peg
 - PVC Primer
 - PVC Cement (Glue)