



Place the front flap on top of the front Cover, Place tape on top of Front flap (1) then wrapping the tape the to back side(2), cut off any excess.