

Drill the mounting holes for the electronics stack based on the mounting plate requirements and the hardware used to mount it.

Drill all arm mounting holes to clear 6-32 thread screw; typically 1/8"

For more information about Civilian UAVs Visit www.dronespeak.com

Widebody Multirotor Plate 1a Doug Starwalt 30 JUN 2013