



DETAIL A

Attach ball joint and tighten mounting clamp in place

Use Flat Head 4-40 x 3/4" Screws, nuts & washers to attach assembly. Screw heads to be facing the inside of the tube.

Secure Power Supply flush with edges with zip ties (Drill holes in base as required for mounting)

