



Mount the 1x2 Assemblies approximately as shown. The assembly should slope down 2-3°

Screw short 1x2 to long 1x2 as shown before attaching to assembly

Install Ball Feed Guard using a staple gun

Install 2 Pole Mounts (printed parts) flush to the end of 1x2s using #6 Wood Screws