

CR2032 battery holder. Handy for use in the Paper Circuit Strawbees project.

- In square one put a piece of copper foil tape so that it goes off the paper on the top. That will be the positive lead.

 In squares 2 and 5 put one long piece of copper foil tape so that it goes off the paper on the bottom. That will be the negative lead.
Put CR2032 battery negative side down on square #2

- Fold squares 1 and 4 onto squares 2 and 5 (left to right). Fold squares 3 and 6 (right to left) on top of squares 1 and 4.

- Fold the paper in half bottom to top.



