



Instructions:

- 1) Print both pages full size (100%).
- 2) Cut out the rectangular sections from each page.
- 3) Line up the A and B arrows and tape the two sections together.
- 4) Wrap the paper around a 15 5/8" length of 3/4" schedule 40 PVC pipe. Make sure that the orange arrows line up together.
- 5) Cut out the white area using a dremel with a cutting wheel.
- 6) Drill the 1/8" and 1/16" holes.

Worm Gear Carriage Body Template Page 2 of 2

