



- 1) Drill live center hole
- 2) Turn 60mm length down to 9.5mm
- 3) Turn 15mm to 5mm
- 4) Turn shaft part down to 8mm