

BOM

Component	Value	Quantity Per PCB
PCB	ATTiny Adapter board	1
C1-C2	100n	2
D1	LED	1
JP1-JP6	3 Jumper pins	6
Q1	BC547	1
R1	10k	1
R2	1k	1
U1	Header pins for ZIF Socket on ISP Shield	1
U2/U3	20p ZIF Socket for ATTiny85 / ATTiny2313	1
U4	14p or 16p ZIF Socket for ATTiny84	1