



These lines show the tape wrapped around from the front of the card. The tape should continue to intersect with the tape to connected to the battery pack. Press it firmly onto the other tape for a good connection.

Fold Lines

Continues around to other side