



Z Rail Spacer

Only 0.125" deep

Only 0.125" deep
X Cart End Left

X Cart End Right

Z-Rail Back

X Cart Connector 1 (Outer)

X Cart Connector 2 (Middle)

X Cart Connector 3 (Inner)

Beam Middle

Beam Middle

Base

Right Cart Inside

Right Cart Outside

Left Cart Inside

Only 0.125" deep

Only 0.125" deep

25.00"

30.00"

0.75"

0.00"

0.00"

Beam Bottom

Ruler

Motor Spacer

Z Cart End Space

Z Cart Holder (A)

Z Cart Holder (A)

X Bearing Block Holder

X Bearing Block Holder

Z Cart End Nut

Motor Spacer

Y Block Holder

Y Block Holder

Y Block Holder

Y Block Holder

Motor Spacer

Belt Holder

Belt Holder

Beam Cap

Beam Cap

Z Cart Holder (B)

Belt Holder

Belt Holder

Z Cart Holder (B)

Z Cart End Nut

Z Cart End Nut

Z Cart End Nut