



Notes:

- 1) You will need two copies of the first path on the far left, it sandwiches the slider (second path from the left) so it slides smoothly and doesn't scratch the written side of the CD.
- 2) Keep the artwork you add to path number 2 within the boxes shown - this will keep it visible within the lower window and out of the path of the top pin that passes through all other parts.
- 3) The center box on last path (far right) is the space that exposes the face of the disk while inside the case. Stay roughly within the guide provided when creating your shape.
- 4) See "Creative Starters" for other themed ideas.
- 5) Enjoy.

