
Avoid rotating the day-of-the-week hand between 22:00 and 02:00.
To rotate the month hand, raise the main arm.
Opening to raise the main arm.
The date hand can be rotated clockwise only. From 31st to 1st, raise the main arm.
JAN
MAR
MAY
JUL
SEP
NOV
SUN
MON
TUE
WED
THU
FRI
SAT
1 3 5 7 9 11 13 15 17 19 21 23 25 27 29
0 2 4 6 8 10 12 14 16 18 20 22