

YARDAGES:

- Three pieces of fabric; each needing to be about 8"x 14". I mention sizes because this is a great project for scraps. Cotton is recommended due to absorbency and comfort
- 21" (for small) or 22" (for large) of narrow elastic, cut into two equal pieces
- ALTERNATELY cut a 4 yard length of ribbon, fabric tubing, or even a narrow flat fabric strip, if elastic is not available or if someone finds it uncomfortable.

SEAM ALLOWANCES are all 5/8" (1.5cm) and included on the pattern piece.

DEFINITIONS: Fig 1

- Outer Fabric (OF); the fabric you will see when the mask is worn.
- Inner Liner Fabric (ILF); the ham in the sandwich. This is not visible.
- Lining Fabric (LF); The inside fabric which will touch the face.

CUT the pattern out in the size you are choosing; small is for children and tiny-headed adults, large fits most adults.

FOLD each piece of fabric in half to make an 8"x7" rectangle. It is ok to stack them all up and cut once if your hand and scissors can do it. If not, just do each piece separately.

LAY the pattern on the fabric, side on the straight grain, and pin. PRO TIP; fold the outer fabric (OF) and the lining fabric (LF) **right side in** *before* cutting.

CUT the fabrics.

MARK the pleat on just the outer fabric, mark on both sides of the center seam. This pleat will be done later with all layers together. Use chalk or fabric marking pen if you have it, pencil or a running stitch if you don't. If marking just doesn't work, read on! I have a solution for that, too.

LAY the inner liner fabric (ILF) on either side of the outer fabric (OF). The order should be ILF, OF, OF, ILF. **Fig 2** Also, be sure the LF is right sides together, just separately (LF, LF).

STITCH The centers together from point **A** to point **B**, with a 5/8" (1.5cm) seam allowance on both the four layer OF/ILF and the LF. Stitch from edge to edge, back stitching at both ends. A shorter stitch will give you leeway if you clip too closely by accident.

CLIP curves using Vs. The point of the V should be close to but not touching the stitching line. Fig 3

PRESS center seams open with a hot steam iron (trust me, this makes life easier). The curved tip of the ironing board works well. Alternately, using a zig zag stitch, stitch along the center seam, preferably from the wrong side to be sure the seam is stitched open.

PLACE connected outer fabric/inner liner fabric together with lining fabric, **right sides** together. Line up the center seams on top and bottom and pin. Pin corners and any other place you are concerned about. ${\bf Fig~4~A}$

SEW all the way around **except** between the notches on **one** side. **Fig 4 B**

CLIP all corners diagonally. Clip curves. Fig 4 C

TURN mask right side out and **press**, making sure the corners are popped out nicely and the open edge is even with the outer fabric and lining fabric aligned. **Fig 5**

PLEAT where marked on the pattern (and hopefully on the mask) by folding the mask at the mark, setting the needle about 3/16" in and stitching back and forth about 3 stitches to create a bump. Sometimes the mark is hard to see. Feel for the edge of the seam inside and fold there, then stitch. Do this on both sides of the center seam. **Fig 6 A** *These pleats are optional—but the fit is better with them.*

STITCH all the way around the mask, between 1/8" and 3/16" from the edge. When you get to the pleated bump, hold it away from the center seam and stitch back and forth one or two stitches to secure it, then continue on around the mask. PRO TIP; find or draw a mark on the presser foot and keep the edge aligned with that mark. I love Sharpies! If drawing on the presser foot is abhorrent, put a piece of tape down and draw on that. Also, I use the very tip of a seam ripper to hold down the bump to help the machine stitch it down. Go slowly so you don't hit the ripper with your needle and break it.

MEASURE in from the side 1/2" mark the line **CD**, fold and press to the inside. **Fig 6 B**

STITCH near the edge of the folded part to create a channel for the elastic. Fig 7

THREAD elastic through the channel using a bodkin, bobby pin or safety pin to get it through the channel. Then tie an overhand knot **Fig 8** Check the fit and adjust as needed. Slide knot into channel for comfort.

ALTERNATIVE to elastic; measure 4 feet of ribbon, a fabric tube, or flat folded and stitched fabric and thread through the elastic channels as shown. **Fig 9**

