```
//Libraries
     #include <LiquidCrystal.h>
                                       //LCD library
     #include <SoftwareSerial.h>
                                       //SoftwareSerial library
 4
     #include <OneWire.h>
     #include <DallasTemperature.h>
     #include <SPI.h>
                                       //SPI library for SD card
 7
     #include <SD.h>
                                       //SD card library
 8
 9
     //Serial ports
10
     #define orprx 2
                                             //define what pin orp rx is going to be
     #define orptx 3
                                             //define what pin orp Tx is going to be
11
12
     SoftwareSerial orpserial(orprx, orptx); //define the ORP soft serial port
     #define phrx 14
13
                                             //define what pin pH rx is going to be
     #define phtx 15
                                             //define what pin pH Tx is going to be
14
15
     SoftwareSerial phserial(phrx, phtx);
                                            //define the pH soft serial port
16
17
     //Temperature probe setup
18
     #define ONE_WIRE_BUS 19
                                              // Data wire is plugged into pin 19 on the Arduino
19
     OneWire oneWire(ONE WIRE BUS);
                                             // Setup a oneWire instance to communicate with any OneWire devices
20
     DallasTemperature sensors(&oneWire);
                                             // Pass our oneWire reference to Dallas Temperature.
     DeviceAddress insideThermometer = \{0x28, 0xB4, 0x6B, 0xC8, 0x04, 0x00, 0x00, 0x1F\};
21
                                                                                              // Assign the addresses of
     your 1-Wire temp sensors.
22
2.3
     //define ORP variables
24
     char orp data[20];
                                           //20 byte character array to hold ORP data
25
     char orp computerdata[20];
                                          //20 byte character array to hold incoming data from a pc
     byte orp received from computer=0;
                                          //we need to know how many character have been
26
     received.
     byte orp received from sensor=0;
                                           //we need to know how many character have been received.
27
28
     byte orp_startup=0;
                                           //used to make sure the arduino takes over control of the ORP Circuit properly.
     float ORP=0;
                                           //used to hold a floating point number that is the ORP
29
     byte orp_string_received=0;
                                           //used to identify when we have received a string from the ORP circuit
30
31
32
     //define pH variables
33
     char ph data[20];
                                          //20 byte character array to hold incoming pH
34
     char ph computerdata[20];
                                          //20 byte character array to hold incoming data from a pc
35
     //byte pc debug=0;
                                          //if you would like to debug the pH Circuit through the serial
     monitor(pc/mac/other). if not set this to 0.
     byte ph received from computer=0;
                                          //we need to know how many characters have been received from
36
    computer
     byte ph received from sensor=0;
                                          //we need to know how many characters have been received from pH sensor
37
```

```
byte ph startup=0;
                                          //used to make sure the arduino takes over control of the pH Circuit properly.
38
                                          //used to hold a floating point number that is the pH.
     float ph=0;
39
     byte ph string received=0;
                                          //used to identify when we have received a string from the pH circuit.
40
41
42
     //LCD set up
     LiquidCrystal lcd(8, 9, 4, 5, 6, 7); // select the pins used on the LCD panel
43
44
45
     void setup(){
46
          Serial.begin(38400);
                                      //enable the hardware serial port
47
          orpserial.begin(38400);
                                      //enable the software serial port
                                      //enable the software serial port
48
          phserial.begin(38400);
49
          sensors.begin();
                                      //start up temp probe library
50
          sensors.setResolution(insideThermometer, 10);
                                                             // set the temp probe resolution to 10 bit
          lcd.begin(16, 2);
                                      // start the lcd library
51
52
          SD.begin(16);
53
         pinMode(10, OUTPUT);
54
55
56
57
     void loop() {
58
      sensors.requestTemperatures();
                                             //read Temp probe
59
      printTemperature(insideThermometer);
60
61
       orpserial.listen();
62
       delay(100);
63
       if(orpserial.available() > 0){
                                               //if we see that the ORP Circuit has sent a character.
64
          orp received from sensor=orpserial.readBytesUntil(13,orp data,20); //we read the data sent from ORP Circuit
          untill we see a <CR>. We also count how many character have been recived.
65
          orp data[orp received from sensor]=0; //we add a 0 to the spot in the array just after the last character we
          recived. This will stop us from transmiting incorrect data that may have been left in the buffer.
66
          orp string received=1;
                                                //a flag used when the arduino is controlling the ORP Circuit to let us
         know that a complete string has been received.
67
68
       phserial.listen();
69
       delay(100);
70
       if(phserial.available() > 0){
                                           //if we see that the pH Circuit has sent a character.
71
          ph received from sensor=phserial.readBytesUntil(13,ph data,20); //we read the data sent from ph Circuit untill
          we see a <CR>. We also count how many character have been recived.
         ph data[ph received from sensor]=0; //we add a 0 to the spot in the array just after the last character we
72
          recived. This will stop us from transmiting incorrect data that may have been left in the buffer.
73
         ph string received=1;
                                              //a flag used when the arduino is controlling the pH Circuit to let us know
```

```
that a complete string has been received.
 74
 75
 76
      void printTemperature(DeviceAddress deviceAddress)
 77
 78
          int decPlaces = 0;
                                 // set temp decimal places to 0
 79
        float tempC = sensors.getTempC(deviceAddress);
 80
        if (tempC == -127.00) {
 81
          lcd.print("Error getting temperature");
 82
        } else {
           lcd.setCursor(0,0);
 83
                                 //set position on lcd for pH
 84
           lcd.print("pH:");
 85
           lcd.print(ph, 1);
                                 //send pH to lcd
 86
           lcd.setCursor(7,0);
                                 //set position on lcd for ORP
           lcd.print("ORP:");
 87
 88
           lcd.print(ORP, 0);
                                 //send ORP to lcd
 89
           lcd.setCursor(0,1);
                                 //set position on lcd for Temp
 90
           lcd.print("Temp:");
 91
           lcd.print("C ");
 92
           lcd.print(tempC,decPlaces);
                                           //display Temp in celsius
 93
           lcd.print(" F ");
 94
           lcd.print(DallasTemperature::toFahrenheit(tempC),decPlaces); //convert celsius to farenheit
                                  //we will take a reading ever 10000ms
 95
           delay(10000);
 96
 97
      orpserial.print("R\r");
                                                  //send it the command to take a single reading.
 98
 99
         if(orp string received==1){
                                                  //did we get data back from the ORP Circuit?
100
           ORP=atof(orp data);
                                                  //convert orp data string to ORP float
101
           if(ORP>800){Serial.println("high\r");} //This is the proof that it has been converted into a string.
102
           if(ORP<800){Serial.println("low\r");} //This is the proof that it has been converted into a string.
103
           orp string received=0;}
                                                  //reset the string received flag.
104
105
      phserial.print("R\r");
                                                  //send it the command to take a single reading.
         if(ph_string_received==1){
106
                                                  //did we get data back from the ph Circuit?
107
           ph=atof(ph data);
                                                  //convert ph data string to ph float
108
           if(ph>=7.5){Serial.println("high\r");} //This is the proof that it has been converted into a string.
109
           if(ph<7.5){Serial.println("low\r");} //This is the proof that it has been converted into a string.
110
           ph string received=0;}
                                                  //reset the string received flag.
111
112
113
       long currentTime = millis();
                                                                    // Get the current time in ms (time since program start)
```

128

```
File dataFile = SD.open("datalog.txt", FILE_WRITE);
114
                                                                   //open the file
                                                                   // if the file is available, write to it:
115
        if (dataFile) {
            dataFile.println(currentTime);
                                                                   // logs the time in milliseconds since the program started
116
117
            dataFile.print(",");
                                                                   //inserts a comma
            dataFile.println(ph);
118
                                                                   //logs the pH
            dataFile.print(",");
119
                                                                   //inserts a comma
            dataFile.println(ORP);
                                                                   //logs the ORP
120
            dataFile.print(",");
121
                                                                   //inserts a comma
            dataFile.println(tempC);
                                                                   //logs the temperature in degrees C
122
123
            dataFile.print("\r");
                                                                   //inserts a return character
124
            dataFile.close();
125
126
127
```