Instructions to Build Your Dinobot

So, you desire to make a Dinobot. Don't worry! You will have a dinobot in these easy steps.

<u>Materials</u>

- Scissors
- Tape/Glue
- One Head Piece
- One Body Piece
- Two Arm Pieces
- Two Feet Pieces

Step by Step Instructions:

- 1. Print out the robot PDF file with the required pieces and instructions. Place it on your chosen desk.
- 2. Sit down or stand in a comfortable position to allow you an easier time to cut and tape your robot together.
- 3. Make sure to cut across the solid black lines and fold on the dotted lines of the piece that is called **BODY**. Make sure to tape together the edges that are greyed out.
- 4. Repeat step 3 with the **HEAD**. Make a loop of tape or a dab of glue and place the head piece on top of the body section labeled "**HEAD GOES HERE**."
- 5. Cut across the solid black lines and fold on the dotted lines of the pieces that are labeled **FEET**. Make sure to tape together the edges that are greyed out.
- 6. Tape the foot flaps (greyed out) area to the marked areas on the body that say "**FOOT GOES HERE**."
- 7. Cut across the solid black lines and fold on the dotted lines of the pieces that are labeled **ARMS**. Attach them to the body.
- 8. Cut out the tail piece. Slide it into the tail slit.
- 9. HURRAH! You made a dinobot! Rejoice!