


You will need to prepare some separation or parchment paper to hold the ribbon after you cut it. As the gear is a little more than 10mm wide, the cutting guide below is set for 20mm

20mm



110mm You will want to cut the ribbon sheets to length, so you can save the unused parts for later. You basically need a ribbon to be around 110mm long to span the alignment jig and truss.
